Photo cells connection to RDS52-SY control

A1.1

RDS 52-SY control

Remote control socket

fuse

GND B A VCC encoder port

Dial the code switch function

output signal

- COM
- OPEN
- CLOSE
- STOP
- RAD
- 24V
- COM
- INF

Mechanical limit

- OP
- CO
- CL

Display socket

transformer

Button socket

- NC
- COM1
- NO

Emergency Stop

relay   relay

FUSE

L1 L2 L3 N PE U V W D1 D2

Power line port

Photo cells

| NC |
COM
+
AC/DC	S1	S2

+

−

COM
OPEN
CLOSE
STOP
RAD
24V
COM
INF

SEE DOOR MANUAL, SET - PARAMETER P2-07 to 1