



Installation manual for High Speed Doors

Riga Door Systems


Model: RDS 3000





Riga Door Systems
we open the world

Malas, Vetras, Marupe LV-2167, Riga district, Latvia; web: www.rigadoors.lv

Designed by	VPA	Sheet Format	A3	Date	2024-07-05	Install manual HSD RDS3000		
						HSD RDS3000	Rev. 2	Sheet 1 / 11



Producer: Riga Door Systems
 SIA
 Malas, Marupe LV 2167, Latvia
 Type: power operated high
 speed doors RDS3000
 Serial number, year: 1-2023
 Opening: 4000x3500(WxH)
 Wind load class: 1
 Air permeability class: 1
 Water penetration class: 1
 Thermal resistance W(m2K): 6,0
 EN13241-1:2003+A2:2016




$W=W$
 $H=H$



Designed by	VPA	Sheet Format	A3	Date	2024-07-05	Install manual HSD RDS3000		
						HSD RDS3000	Rev. 2	Sheet 3 / 11

A.4














Riga Door Systems
we open the world

Malas, Vetras, Marupe LV-2167, Riga district, Latvia; web: www.rigadoors.lv

Designed by	VPA	Sheet Format	A3	Date	2024-07-05	Install manual HSD RDS3000		
						HSD RDS3000	Rev. 2	Sheet 4 / 11

A.5




Riga Door Systems
we open the world

Malas, Vetras, Marupe LV-2167, Riga district, Latvia; web: www.rigadoors.lv




Designed by	VPA	Sheet Format	A3	Date	2024-07-05	Install manual HSD RDS3000	
HSD RDS3000						Rev.	Sheet
						2	5 / 11

A.6

1.



2.






Riga Door Systems
we open the world

Malas, Vetras, Marupe LV-2167, Riga district, Latvia; web: www.rigadoors.lv

Designed by	VPA	Sheet Format	A3	Date	2024-07-05	Install manual HSD RDS3000		
						HSD RDS3000	Rev. 2	Sheet 6 / 11

A.7



Riga Door Systems
we open the world

Malas, Vetras, Marupe LV-2167, Riga district, Latvia; web: www.rigadoors.lv

Designed by	VPA	Sheet Format	A3	Date	2024-07-05	Install manual HSD RDS3000		
						HSD RDS3000	Rev.	Sheet
							2	7 / 11

A.8










PHOTO CELL INSTALATION



! $\varnothing 13$




Riga Door Systems
we open the world


Malas, Vetras, Marupe LV-2167, Riga district, Latvia; web: www.rigadoors.lv

Designed by	VPA	Sheet Format	A3	Date	2024-07-05	Install manual HSD RDS3000		
						HSD RDS3000	Rev. 2	Sheet 8 / 11




A.9



DOOR LINE PHOTO CELL INSTALATION



! Ø3




Riga Door Systems
we open the world



Malas, Vetras, Marupe LV-2167, Riga district, Latvia; web: www.rigadoors.lv

Designed by	VPA	Sheet Format	A3	Date	2024-07-05	Install manual HSD RDS3000		
						HSD RDS3000	Rev. 2	Sheet 9 / 11


B.1 Option- Roll housing






B.2 Option- Motor housing



When mounting both the motor and guide housings - cut the guide housing along with the motor housing



B.3 Option- guide housing



Riga Door Systems
we open the world

Malas, Vetras, Marupe LV-2167, Riga district, Latvia; web: www.rigadoors.lv

Designed by	VPA	Sheet Format	A3	Date	2024-07-05	Install manual HSD RDS3000		
						HSD RDS3000	Rev. 2	Sheet 11 / 11