


# Opto eye + Photo cells conection to RDS 52-SY control

RDS 52-SY control



SEE DOOR MANUAL, SET - PARAMETER P2-07 to 1  
PARAMETER P2-08 to 1