


# Slide bolt switch connection to RDS 52-SY control

RDS 52-SY control



SEE DOOR MANUAL, SET - PARAMETER P2-08 to 1

