



# Slide bolt switch connection to RDS 52-Y control

RDS 52-Y control



SEE DOOR MANUAL, SET - PARAMETER P2-08 to 1

