


TS970, TS971 connection to Light Curtain

CONTROL UNIT TS970/TS971



1. 2.1-2.2 original resistor
2. To activate impulse operation
UP-DOWN - Program 1 set to 3

