


# TS970, TS971 connection to Optical safety edge system

## CONTROL UNIT TS970/TS971



1. To activate impulse operation  
UP-DOWN - Program 1 set to 3

