


TS970/ TS971 connection to RDS 100 radar

CONTROL UNIT TS970/TS971



- 1. 2.1-2.2 original resistor
- 2. To activate impulse operation
UP-DOWN - Program 1 set to 3

